

Additional Info for installation of eztone magnetic entry exit door chimes

800 570 1861 eztone@hotmail.com

With the chime installed And the LID OFF
Close the door tightly

And make sure the chime piston
is not making contact with the chime sounder bar

with door closed if piston continually
Hits chime sounder bar it will ruin
the chime in six months or a year
Not covered by warranty

with the door tightly closed
open the door one inch
and close the door
the chime should continue
the "ringing" sound.
If the ringing sound stops
when you do this
the chime box is too close to the door
NOTE (bracket not need for pull doors)

also note that this chime installs
easier with 1/2 inch or 3/4 inch
size 1/4 inch hex head
you need 1/4 inch hex head
driver for this
rather than the screws (philips)
that come with the unit